

Kod produktu: P30155



## **P30155 Uchwyt zapadka przyssawy do modeli P30024, P30025, P30026, P30027, P30028, P30101, P30102, P30103 - PIHER**

**56,35 zł**~~67,90 zł~~

**Uchwyt zapadka przyssawy do modeli P30024, P30025, P30026, P30027, P30028, P30101, P30102, P30103 - PIHER P30155**

**Do modelu**

P30024, P30025, P30026, P30027, P30028, P30101, P30102, P30103